


Cable Clamp documentationFLX UC 500 Cable Clamp



Use the cable clamp to secure the cables connected to the UC products and support that they are not unintentionally removed.

(1) Place the bottom part of the cable clamp into the cable cavity of the UC unit before connecting the cables. (2) Once the power and USB cables are connected and fit into the respective areas of the cable clamp, (3) place the second part of the cable clamp on top, and fasten the clamp using the two screws included with the kit.



Yamaha Unified Communications, Inc.

144 North Road #3250
Sudbury, MA 01776 USA
+1 800-326-1088
uc-sales@music.yamaha.com


Yamaha UC EMEA

190 High Street Tonbridge, Kent
TN9 1BE, UK
+44 (0)1732 366535
uc-salesemea@music.yamaha.com

Yamaha UC APAC

+852.8108.8820
uc-salesapac@music.yamaha.com

FLX UC 1000 and FLX UC 1500 Cable Clamp



Use the cable clamp to secure the cables connected to the UC products and support that they are not unintentionally removed.

(1) Place the bottom part of the cable clamp into the cable cavity of the UC unit before connecting the cables. (2) Once the USB and extension microphone cables are connected and fit into the respective areas of the cable clamp, (3) place the second part of the cable clamp on top, and fasten the clamp using the two screws included with the kit. The Network cable sits outside of the cable clamp.



Yamaha Unified Communications, Inc.

144 North Road #3250
Sudbury, MA 01776 USA
+1 800-326-1088
uc-sales@music.yamaha.com

Yamaha UC EMEA

190 High Street Tonbridge, Kent
TN9 1BE, UK
+44 (0)1732 366535
uc-salesemea@music.yamaha.com

Yamaha UC APAC

+852.8108.8820
uc-salesapac@music.yamaha.com